

## **Section 1 Hardware and ROMS**

### 1.1 VX systems

1.1.1 Adding memory to 80386-based products

1.1.2 VX systems console dimensions

1.1.3 MDA card

This card only may be used on VX systems on network

1.1.4 Disk capacities of VX systems

1.1.5 VX SCSI Sub-System

Hardware summary

1.1.5.1 Introduction

1.1.5.2 Scope

1.1.5.3 VX system box

1.1.5.4 I/O board and cabling

1.1.5.5 Full height tape drive

1.1.5.6 VX Tape drive error codes

1.1.5.7 70MB hard disk drives

(Rodime R03085S)

1.1.5.8 150 and 300MB hard disk

(Maxtor XT-3170 and XT-32800)

1.1.5.9 SCSI Board

1.1.6 ROM BIOS 1.1.6 hidden INT

13H call function 80H

1.1.7 Terminators on DSU Hard

Disk drives, Tape drives etc.

### 1.2 XEN-i 386

1.2.1 Adding memory to 80386-based products SIMMS which may be used

1.2.2 RAM expansion kits for XEN-i 386 and AM cards

1.2.3 XEN-i 386 hard disk drives

1.2.4 XEN-i 386/30 and Western

Digital Controller

1.2.5 386 16Mhz AT Motherboard

1.2.6 386 Error Beep Codes

1.3 XEN-i, XEN-Xi, XEN-i AWS

1.3.1 Backlights on keyboards (to be

removed)

1.3.2 Serial cable to connect to  
Apricot PC/Xi

1.4 XEN-i Workstation (reserved for  
future use)

1.5 XEN MF, XEN, XEN  
Workstation

1.5.1 Backlights on keyboards (to be  
removed)

1.5.2 Serial port pinouts for XEN  
range

1.6 Apricot PC/Xi and F-range

1.6.1 Serial cable for Apricot PC/Xi  
to XEN-i range

1.7 Printers

1.7.1 Printers for VP-Planner

1.7.2 Writer 16, 16c, 17,21,32

Duty cycle for these printers

1.7.3 Drum replacements for Apricot  
Laser printer

Recommended source of supply

1.7.4 Apricot Laser Fault reports for  
emulations

How to report faults

1.7.5 SEM command for setting  
emulation mode on Apricot laser

Undocumented feature that could  
extend the life of your EEPROMs

1.7.6 Paper in the Apricot laser

Use only suitable paper

1.7.7 Fujitsu printers - writers 17,21

1.7.8 Status page service information  
for the Apricot Laser

1.7.9 Apricot (Kyocera) laser ROMs

1.7.10 Returning Laser printers for  
repair

1.8 Add-ons

1.8.1 PX-Adapters

How to fit boards with insulating  
sheets

- 1.8.1.1 PX-Adapter – new version
- 1.8.2 Apricot Modems - current devices, drivers and interfaces
  - 1.8.2.1 Modem hardware
  - 1.8.2.2 Modem drivers
  - 1.8.2.3 Modem interfaces and commands sets
  - 1.8.2.4 Network support
  - 1.8.2.5 Driver interconnectability
  - 1.8.2.6 Suggestions for usage
  - 1.8.2.7 Documentation
  - 1.8.2.8 Statutory information
- 1.8.3 Memory map for Quad cards
  - 1.8.3.1 Quad card and PX-Adapter - new version
- 1.8.4 Numeric Co-processors
- 1.8.5 AM boards
  - 1.8.5.1 4 MB Memory upgrade kit and AM boards
- 1.8.6 1 MB memory module for PC/s range and PC-286
- 1.8.7 14” Zenith Paper White monitor
- 1.8.8 VGA Cards and Monitors
- 1.8.9 Installation of Taxan HR19 Monitors
- 1.8.10 Adding An External 5.25” Floppy Drive
- 1.8.11 TS150 (Wangtek)
- 1.8.12 Co-Processors
  
- 1.9 Apricot PC/s range
  - 1.9.1 Paper white monitors for PC-286 and PC/s range
  - 1.9.2 EGA adapters and Windows 2/Windows 386
  - 1.9.3 Xen-i 286 Twin
  - 1.9.4 Xen-i ROM BIOS Release history
  - 1.9.5 Xen-i PC/S Technical Reference Manual
  - 1.9.6 Paradise VGA Cards with Xen-i (PC/S)
  
- 1.10 PC-286
  - 1.10.1 Available power

1.10.2 Recommended parallel cable  
for PC-286

1.10.3 Serial Port Pinouts

1.10.4 PC286 and the Microsoft  
Mouse

1.10.5 PC286 Repeating Keys

1.11 Xen-i 386-50/100 (tower  
systems)

1.11.1 BOS on tower systems

1.11.2 Keys for tower systems

1.11.3 Filters on tower Systems

1.12 Floppy Disk Drives

1.12.1 XEN-i 3.5" Disk Drive

Diagnostics

1.13 Hard Disk Drives (Winchesters)

1.13.1 Seagate 46.8Mb RLL ST-  
157R 28ms

1.13.2 Seagate 46.8Mb RLL ST-  
157R 40ms

1.13.3 Maxtor 150Mb and 300Mb

1.13.4 Winchester Drive Parameter  
Table

1.13.5 Hard Disk Formatting on New  
Machines

1.14 Apricot Qi (MCA Architecture)

1.14.1 SIN Number

1.14.2 Qi Serial Cable

1.14.3 Windows 386 and Paperwhite  
Monitors on Qi and Xen-s

1.14.4 Qi ROM Release History

1.14.5 Clearing the CMOS RAM on  
Qi machines

1.14.6 Qi Reading IBM PS/2 Floppy  
Disks

1.14.7 Qi Beep Error Sequence

1.14.8 Latest Release of Security  
Processor

1.14.9 Disabling on-board Ethernet

1.14.10 Security.sys

1.14.11 Qi 300 Range and  
Performance

1.14.12 40MByte Tape Drive Jumper  
Settings

## 1.15 XEN-S (IBM AT Architecture)

### 1.15.1 Reading 720 Disks

### 1.15.2 AM Cards

### 1.15.3 Reading Disks formatted on an IBM PS/2

## 1.16 Serial Cables

### 1.16.1 Maximum Cable Lengths

### 1.16.2 Serial Printer Cables

### 1.16.3 Serial Cables for PS8/2Laser Printers

### 1.16.4 Synchronous Comms Port Splitter Cable

## 1.17 Xen-i 286 (12.5MHz Xen-S Style)

### 1.17.1 1Mb Memory Module for Xen-i 286 (XB9916)

### 1.17.2 AEMM on Xen-i 286

## 1.99 General

### 1.99.1 Service reports

Ensure that users keep copies of service reports

### 1.99.2 Benchmarks of various computers

Comparison of Apricot range and other manufacturers

### 1.99.3 Memory on IBM compatibles

#### 1.99.3.1 Apricot Extended/Expanded memory Utilisation

Windows 386 Expanded Memory

### 1.99.4 Current ROM revision levels

### 1.99.5 Cross Reference Chart of Old Xen-i Range

### 1.99.6 Invalid Setup Problems

Booting on MS-DOS 3.30

### 1.99.7 TS60/5 Tape Drive

Installation & Configuration

### 1.99.8 Prevention of Mains

Interference and Power Failure

### 1.99.9 Cross Reference Chart of Current Range

## Section 2 Software

2.1 Systems software - XEN-i range  
- Single user

2.1.1 Formatting 3.5" diskettes on  
XEN-i/XEN-Xi

Clarification of how to format  
Various capacity disks

2.1.2 Apricot Microscreen Editor  
Description and example of MS.EXE

2.1.3 Timebomb

Can be used to install Autocad

2.1.4 Windows

2.1.4.1 Converting Text Files in  
Windows Write Ver 1.03 and 2.03

2.1.4.2 Windows 386 on Xen-i  
386/30

2.1.4.3 Windows 2

2.1.5 Formatting of Winchesters on  
XEN-i systems

2.1.6 MS-DOS 3.30 features

2.1.6.1 AEMM.SYS

2.1.6.2 FDISK.EXE

2.1.6.3 FORMAT.EXE

2.1.6.4 MODE.EXE

2.1.6.5 MOUSE.EXE

2.1.6.6 MSCALC.SYS

2.1.6.7 RECOVER.COM

2.1.6.8 SETUP.EXE

2.1.6.9 TAPES.SYS

2.1.6.10 TRESTORE.EXE

2.1.7 Apricot Shadow Disk system

2.1.8 Windows 386

2.1.9 Increasing number of files that  
can be currently open in DOS 3.3

2.1.10 SYS.COM

2.1.11 Device Driver and TSR  
Interrupt Hooking Practices

2.1.12 OS/2 Overview

2.2 Systems software - Apricot  
architecture - Single user

2.2.1 MS.EXE

2.2.2 Formatting 3.5" disks

How to format IBM format 720k  
disks

2.2.3 Windows paint 1.03

2.3 Applications software

2.3.1 Applications upgrades to latest  
IBM versions

Prices and how to obtain all available  
upgrades

2.3.2 Ability on the XEN-i

Requirements for it to run

2.3.3 Microsoft Multiplan 3.0  
features

2.3.4 Microsoft Project 3.0 features

2.3.5 Microsoft Word 3.10 features

2.3.6 Microsoft Rbase 1.01 features

2.3.7 Microsoft Chart 2.0 features

2.3.8 VP-Planner printers

2.3.9 Apricot Accountant

PACT Associates now offer sales  
and support

2.3.10 Communications software  
outlines

2.3.11 Windows Terminal

2.3.12 Supercalc 4 version 1.1

2.3.13 Autocad with VGA Monitors

2.3.14 Apricot Architecture to IBM  
Architecture Software Upgrades

2.4 Languages

2.4.1 GWBASIC Compiler on XEN

2.4.1.1 Opening devices as files

2.4.1.2 GWBASIC PLAY statement

2.4.2 Microsoft FORTRAN 4.n

features

2.4.3 Microsoft Basic version 6.0

2.5 Desk Top Publishing (DTP)

2.5.1 Pagemaker Vi

2.5.2 Pagemaker V3

2.5.3 Ventura

2.5.4 Micrografx Designer

2.6 Applications Questions and  
Answers

2.6.1 Clipper

- 2.6.2 Dflasc
- 2.6.3 Excel
- 2.6.4 Lotus 1-2-3
- 2.6.5 Multiplan
- 2.6.6 Supercalc
- 2.6.7 Superwriter
- 2.6.8 Word
- 2.6.9 Wordcraft
- 2.6.10 Wordperfect
- 2.6.11 Wordstar Profesional
- 2.6.12 Wordstar 2000
- 2.6.13 Multimate Advantage
- 2.6.14 Foxbase Plus(386)

## 2.7 Communications Software

- 2.7.1 ICL
  - 2.7.1.1 TANGO from Network Designers Ltd
  - 2.7.1.2 CONNECT C03 and CONNECTOSI from Megascybe
  - 2.7.1.3 PC29 from GB Computers
- 2.7.2 IBM
- 2.7.3 DEC
- 2.7.4 Honeywell/Sperry/Burroughs
- 2.7.5 Honeywell
- 2.7.6 BACS (Banks Automated Clearing Service)
- 2.7.7 Viewdata
- 2.7.8 Remote Access to Networks
- 2.7.9 Mail
- 2.7.10 X400
- 2.7. 1 1 Asynchronous Communications Software
- 2.7.12 Desktop Communications (DTC)

Package Overview

## 2.8 Systems Software - Micro Channel Architecture

- 2.8.1 Qi Backup and Restore

## 2.99 General

- 2.99. 1 Do not Mix'n'Match software

Why you should always use officially released disk packs

## **Section 3 Multi-user**

- 3.1 Hardware (Cabling etc)
  - 3.1.1 Point 32 to VX upgrade  
Explaining the finer points
  - 3.1.2 Ethernet Card (Quick Reference no. 1)
  - 3.1.3 New tap box approval number
  - 3.1.4 Omninet2 cards in 386 machines
  - 3.1.5 VX systems and Omninet2
  - 3.1.6 Approved tape media for VX servers
  - 3.1.7 VX-Net 3 Authorization Key
  - 3.1.8 Quad Card in N/X Server
  - 3.1.9 Configuring VX Servers with no MDA card,  
for VX-Net ID. IC, not Applicable to VX-Net 3
  - 3.1.10 PS8 Printers Attached to Network Servers
  - 3.1.11 Mains Requirements for Network Installations
  
- 3.2 Network Software
  - 3.2.1 Network Software Release Numbers  
VX-NET 3.11 and 3.1 Software Overview  
VXNET 3 Software & Documentation
  - 3.2.3 Network Program Specifications and Release Histories
    - 3.2.3.1 PCSHARE Overview
    - 3.2.3.2 AMLOAD.EXE
    - 3.2.3.3 BOOTSrv.EXE
    - 3.2.3.4 CACHE.EXE
    - 3.2.3.5 CONSOLE.SYS
    - 3.2.3.6 ETHERCOM.EXE and ETHERCOM.SYS
    - 3.2.3.7 ETHERNET.SYS
    - 3.2.3.8 LOGON.EXE, LOGOFF.EXE & USE.EXE
    - 3.2.3.9 MINSES.EXE
    - 3.2.3.10 MODEMRDR.SYS,

- MODESRV.EXE &
- MODEUSE.EXE
- 3.2.3.11 MT.EXE
- 3.2.3.12 NBSTAT.EXE
- 3.2.3.13 NETBIOS.EXE
- 3.2.3.14 NETDISK.SYS
- 3.2.3.15 NETGEN.EXE
- 3.2.3.16 NEXTDISK.EXE
- 3.2.3.17 OMNINET2.SYS
- 3.2.3.18 PCSHARE
- 3.2.3.19 QUAD
- 3.2.3.20 SERVER.EXE
- 3.2.3.21 SERVER.SYS
- 3.2.3.22 XPORT.EXE

### 3.2.4 Network Applications

- 3.2.4.1 Lotus 1-2-3 on Xen Workstation
- 3.2.4.2 Omnis Quartz multi-user performance
- 3.2.4.3 Installing Supercalc 4 on Apricot MF and VX Networks
- 3.2.4.4 Windows 2/386 on a Network
- 3.2.5 Languages

### 3.3 Network problem solving

### 3.4 XENIX

- 3.4.1 Configuring Apricot T30 and T60 terminals
  - 3.4.1.1 The Apricot T30
  - 3.4.1.2 The Apricot T60
    - 3.4.1.2.1 T60 Display screen
    - 3.4.1.2.2 General
    - 3.4.1.2.3 Keyboard
    - 3.4.1.2.4 Communications
    - 3.4.1.2.5 Miscellaneous
    - 3.4.1.2.6 Other Screens
    - 3.4.1.2.7 Finishing Setup
  - 3.4.1.3 Baud Rates
- 3.4.2 Parallel printers and system performance
- 3.4.3 Apricot Quad Card Configuration

### 3.4.4 Apricot Chase AT4 AT8, AT16 Serial I/O Controllers

#### 3.4.4.1 Terminal lockout

#### 3.4.4.2 Chase cards and modem usage

#### 3.4.4.3 DMA Channel 5 Active

#### 3.4.4.4 Upgrading to Xenix 386

### 3.4.5 Floppy disk verification under Xenix

### 3.4.6 Using Serial printers under Xenix

#### 3.4.6.1 Special notes concerning the Writer 14

#### 3.4.6.2 Special notes concerning the Diablo 630

#### 3.4.6.3 Switching off banner under Xenix

### 3.4.7 Driving Printers off Apricot T60 terminals

#### 3.4.7.1 Terminal Setup

#### 3.4.7.1' Printer setup

#### 3.4.7.3 Host system

### 3 4.8 Apricot Triplex Modern - operation Guide

#### 3.4.8.1 Installation

#### 3.4.8.2 Operation

### 3.4.9 AM Cards and Xenix 386

### 3.4.10 Fixed disk errors

#### 3.4.10.2 Apricot Xenix 286

#### 3.4.10.3 Apricot Xenix 386 for PC's

#### 3.4.10.4 Apricot Xenix 386 on a VX System

#### 3.4.10.5 General Points

### 3.4.11 SCO Xenix and MS-DOS

### 3.4.12 Release Notes

### 3.4.13 SCSI Tape Drives and Xenix

### 3.4.14 Apricot Map and SCO Xenix

## 3.99 General

### 3.99.1 Installing multi-user upgrades - guidelines

## **Section 4 Documentation**

4.1 XEN-i 386 Technical Reference Manual

4.2 DOS 3.2 manual

4.2.1 Packed Format Backups

4.2.2 Tree Command

4.3 Desktop publishing technical bulletin

4.4 REL6/1A update documentation

4.5 Windows 2 - Windows 386 User Guide

## **Section 5 Miscellaneous**

5.1 Users responsibility for Backup  
Backups must be made regularly

5.2 Help us to help you

All feedback welcome

5.2.1 Technical Support on 021-456-4040

5.3 Trouble-shooting methods

Common sense approach to solving problems

5.4 Questions and Answers

5.5 Data Conversion

5.6 Large Screen Presentations

## **Section 6 Index**